

50Ω SUB-MINIATURE COAX 50/350 SERIES, TPS/TCM JACKS & PLUGS

△ Refers to Cable Group Table, see pages 82-124.
"D" mounting holes are on page 63.

PL50-1 Shown

CABLE PLUG	50Ω	3-lug	PL50- △
WRENCH CRIMP	50Ω	4-lug	PL50FL- △
	50Ω	Threaded	PL350- △

BULKHEAD JACK	50Ω	3-lug	BJ50
FRONT MOUNT, SOLDER POT	50Ω	4-lug	BJ50FL
	50Ω	Threaded	BJ350

Mounting Hole: D6.218

PL50C-001 Shown

CABLE PLUG	75Ω	3-lug	PL50C- △
TOOL CRIMP	50Ω	3-lug	PL50CFL- △
	50Ω	4-lug	PL350C- △
	50Ω	Threaded	

BJ57 Shown

INSULATED BULKHEAD JACK			
FRONT MOUNT, SOLDER POT	50Ω	3-lug	BJ57
	50Ω	4-lug	BJ57FL
	50Ω	Threaded	BJ357

Mounting Hole: D4.187

PL53-1 Shown

PUSH-ON PLUG	50Ω	3-lug	PL53- △
WRENCH CRIMP, TPS/TCM			

TPS PUSH-ON	50Ω		BJ51
SOLDER POT PANEL JACK	50Ω	Ground Lug	BJ51GL

Max Panel Thk: .088

CJ50-1 Shown

CABLE JACK	50Ω	3-lug	CJ50- △
WRENCH CRIMP	50Ω	4-lug	CJ50FL- △
	50Ω	Threaded	CJ350- △

BJ58 Shown

FEED-THRU JACK	50Ω	3-lug	BJ58
	50Ω	4-lug	BJ58FL
	50Ω	Threaded	BJ358

Mounting Hole: D5.190 / D4.190 (Threaded)

CIRCUIT BOARD JACK			
	50Ω	3-lug	CBJ50
	50Ω	4-lug	CBJ50FL
	50Ω	Threaded	CBJ350

BJ59-1 Shown

BULKHEAD JACK	50Ω	3-lug	BJ59- △
WRENCH CRIMP	50Ω	4-lug	BJ59FL- △
	50Ω	Threaded	BJ359- △

Mounting Hole: D4.187